

NUDO NuBarricade™ Reusable Modular Barricade Systems

NUDO NuBarricade™ Reusable Modular Barricade Systems are temporary, sustainable modular walls, designed to be a clean and attractive alternative to traditional wood and drywall barricade structures. NuBarricade™ has a smooth appearance, is lightweight, quick and easy to install and is able to be stored and reused over and over again. This modular system is comprised of ABS composite, kraft honeycomb core and aluminum hardware. NuBarricade™ brings value to working conditions with its ability to adhere a printable surface and to pose as a deterrent where the safety of customers is imperative during construction. NuBarricade™ is ideal for use in malls, airports, office buildings, hospitals and clinics.

| Standard Panels: Table 1 | | | | | | | | |
|--------------------------|--------------------|---------------|--------|--------|-----------------|--------------|-------|-------|
| Panel Widths | Product Code | Panel Heights | | | Panel Thickness | Weights /Lbs | | |
| | | 8' | 10' | 12' | | 8' | 10' | 12' |
| 4' Wide Panels | NUB-BFPXX-[PXXX] | P084 | P104 | P124 | 0.832" | 28.7 | 36.5 | 42.1 |
| 2' Wide Panels | NUB-BFPXX-[PXXX] | P082 | P102 | P122 | 0.832" | 16.8 | 19.8 | 24.4 |
| 1' Wide Panels | NUB-BFPXX-[PXXX] | P081 | P101 | P121 | 0.832" | 10.7 | 12.4 | 15.9 |
| Flexible Corner Panels | NUB-BFPXX-[PXXX] | P080 | P100 | P120 | 0.832" | 12.6 | 16.1 | 19.3 |
| 90 Degree Corner RH | NUB-BFPXX-[HCXXRH] | HC08RH | HC10RH | HC12RH | 0.832" | 8.0 | 8.6 | 10.0 |
| 90 Degree Corner LH | NUB-BFPXX-[HCXXLH] | HC08LH | HC10LH | HC12LH | 0.832" | 8.0 | 8.6 | 10.0 |
| Single Doors | NUB-BFPXX-[DSXX] | DS08 | DS10 | DS12 | 0.832" | 31.7 | 38.6 | 44.4 |
| Double Doors | NUB-BFPXX-[DDXX] | DD08 | DD10 | DD12 | 0.832" | 88.8 | 100.8 | 121.2 |
| 1.93" Wall Attachment RH | NUB-BFPXX-[WCXXRH] | WC8RH | WC10RH | WC12RH | 0.832" | 4.0 | 4.3 | 5.0 |
| 1.93" Wall Attachment LH | NUB-BFPXX-[WCXXLH] | WC8LH | WC10LH | WC12LH | 0.832" | 4.0 | 4.3 | 5.0 |

| Height Extender Panels: Table 2 | | | | | | | | |
|-------------------------------------|--------------------|---------------|--------|--------|-----------------|--------------|-----|------|
| Panel Widths | Product Code | Panel Heights | | | Panel Thickness | Weights /Lbs | | |
| | | 1' | 2' | 4' | | 1' | 2' | 4' |
| 4' Wide Height Extender | NUB-BFPXX-[EXXX] | E014 | E024 | E044 | 0.832" | 5.3 | 9.3 | 14.8 |
| 2' Wide Height Extender | NUB-BFPXX-[EXXX] | E012 | E022 | E042 | 0.832" | 2.8 | 4.0 | 7.2 |
| 1' Wide Height Extender | NUB-BFPXX-E011 | E011 | E021 | E041 | 0.832" | 0.5 | 1.0 | 2.1 |
| Flex Corner Height Extender | NUB-BFPXX-[PXXX] | E010 | E020 | E040 | 0.832" | 2.8 | 4.0 | 7.2 |
| 90 Degree Corner Height Extender RH | NUB-BFPXX-[HCXXRH] | HC01RH | HC02RH | HC04RH | 0.832" | 1.0 | 2.0 | 4.0 |

| Height Extender Panels: Table 2 (cont.) | | | | | | | | |
|--|---------------------|---------------|---------|---------|-----------------|--------------|-----|-----|
| Panel Widths | Product Code | Panel Heights | | | Panel Thickness | Weights /Lbs | | |
| 90 Degree Corner Height Extender LH | NUB-BFPXX-[HCXXLH] | HC01LH | HC02LH | HC04LH | 0.832 | 1.0 | 2.0 | 4.0 |
| 1.93" Wall Attachment Height Extender RH | NUB-BFPXX-[WCEXXRH] | WCE01RH | WCE02RH | WCE04RH | 0.832" | 0.5 | 1.0 | 2.0 |
| 1.93" Wall Attachment Height Extender LH | NUB-BFPXX-[WCEXXLH] | WCE01LH | WCE02LH | WCE04LH | 0.832" | 0.5 | 1.0 | 2.0 |

SPECIFICATIONS: The NUDO NuBarricade panels are manufactured with state-of-the-art laminating equipment and adhesives.

COMPOSITION:

1. ABS- Polystyrene skin, kraft honeycomb core, and aluminum framing.

FINISHED PANEL QUALITY:

1. Both sides of the Panel shall have ABS skins with a hair cell finish. Colors shall be throughout the panel, and manufactured as specified.
2. Panel Dimensions shall be set forth in Table 1.
3. Product quality standards and tolerance for panel weight and thickness shall be set in Nudo Product, Inc. Quality Control Procedures/Standards which are available upon request.
4. Dimensions shall be specified on purchased order, subject to manufacturing tolerances:
Width: ±1/8" (3.2mm)
Length: ±1/8" (3.2 mm)
Squareness: not more than 1/8" (3.2 mm) out of square.
5. Panels shall be installed in accordance with the manufacturer's guidelines as set forth in the installation guide.

STORAGE:

NUDO NuBarricade should be stored horizontally indoors in a cool, dry and well ventilated area on a flat skid, no more than 5 skid high. Panels should never be stored on the floor or an outside wall. Optimum storage conditions are 60°F (16°C) to 75°F (24°C) and 35% to 55% relative humidity.

PRECONDITIONING:

Prior to installing NUDO NuBarricade, remove the packaging materials and masking. Ideally, the room temperature and humidity during acclimation and installation should be the same as the final operation conditions.

PRODUCT LIMITATIONS:

NUDO NuBarricade is designed as an indoor temporary wall barricade system. It should never be exposed to extremely high or extremely low moisture conditions. NuBarricade must always be secured as described in the installation guidelines. Non-compliance with product limitations may affect future performance and voids warranty.

CLEANING INSTRUCTIONS:

NUDO NuBarricade is easy to clean. In most cases, use a clean, damp, non-abrasive cotton cloth and a mild liquid detergent, isopropyl alcohol, household or neutral cleaner. Always rinse with clean water and a clean, non-abrasive cotton cloth. Dry the panels with a soft, clean, non-abrasive cotton cloth.

DO NOT USE: abrasive cleaners with bleach, cleaners with acid, alkali or sodium hypochlorite. They will damage and permanently discolor the surface. Be sure that bottles, rags or other materials with these cleaners never come in contact with the surface. Also, do not use spray adhesives as they can cause a permanent discoloration of the ABS skins.

Examples of harsh cleaners to avoid, include but are not limited to:

- Bleach
- Drain Cleaners
- Metal Cleaners
- Over Cleaners
- Rust Removers
- Tube and Tile Cleaners
- Lime Scale Remover

REMOVAL OF STAINS:

To remove stains, use full strength Isopropyl Alcohol or TexWipes, Fantastik, All Purpose Cleaner, Formula 409, Pine-Sol, or other mild household cleaners. Blot with clean, damp, non-abrasive cotton cloth, and rinse with cleaner water. When recommended cleaner changes its formulation, the change may be harmful to the surface. Nudo Products, Inc. cannot be held responsible for these changes. Follow all directions and warnings on the cleaner label because many are extremely flammable.

Dyes and pharmaceutical products will permanently stain the panels. These include hair dyes and rinses, silver nitrate, laundry bluing, tannic acid, povidone-iodine, dermatological tar compounds, and peroxide. To reduce these stains, apply a paste of baking soda and water on the area to pull out the stain. Do not rub, as the paste will be slightly abrasive. Wipe up the past with a clean, damp, non-abrasive cotton cloth, and rinse with clean water.

We believe all information given is accurate. It is offered in good faith, but without guarantee. Since conditions of use are beyond our control, the user assumes all risks. Nothing herein shall be construed as a recommendation for use that infringes on valid patent or as extending a license under valid permit.

